

## **PATIO HEATER BY ZUBRI**

### INSTRUCTIONS FOR ASSEMBLY AND USE

The Patio Heater is packaged in two containers: 1) a large 2 piece black box held closed by straps and 2) a blue zippered bag for the reflector.

1. Undo the straps and open the box. (Observe how the unit is packed. This will make it easier to return to the box when finished).
2. Remove the main body of the Heater and install the 3 legs, being sure that the spring actuated button is fully locked into the hole in the leg holder.
3. Remove the reflector (top) from carrying bag and install over folding wing nut at top center of the Heater. **Note:** You will probably need to unscrew the folding wing nut about a half inch or more up the threaded rod that it is attached to so that the folding part of the wing nut will clear the hole in the top. (Be sure **not** to unscrew the threaded rod!) After the folding wing nut clears the hole in the top fold it over and tighten it until the reflector is secure.
4. Attach skirt by wrapping around the legs and securing with Velcro at the top and zip closed. Move skirt so that zipper is at one of the legs. (You may wish to install the LPG cylinder before completing this step).

### INSTALLING LPG CYLINDER

1. Be sure that valves on the Heater **and** on the LPG tank are closed. On the Heater, push the valve handle in and turn in a clockwise direction until it stops.
2. Hang the LPG tank from the hook on the bottom of the heater. This is important, as the weight of the tank adds stability to the Heater.
3. Connect LPG regulator to tank and open valve on tank. Check for leaks with a solution of soapy water before proceeding.

### LIGHTING THE HEATER

Follow manufacturer's directions printed on the other side of this sheet.

STEP 1: Turn on gas supply from gas/propane cylinder

STEP 2: Position flame- hold flame under burner head as indicated above.

STEP 3: Start gas flow- push in control knob and turn anti-clockwise

### **GAS WILL IGNITE**

**IMPORTANT: Keep control knob pushed in for at least 15 seconds.** This will allow the safety thermo couple devise to heat up. If the thermocouple is not heated correctly the gas supple will automatically cut off.

NB: If flame goes out for any reason wait 2 minutes and repeat step 2+3.

**TO ADJUST HEAT** – Push in control knob and turn anti-clockwise to increase heat or clockwise to reduce heat.

**TURN HEATER OFF + MAKE SAFE** by pushing in control knob and turning clockwise until stop. Flame will go out. TURN OFF gas supply on gas/propane cylinder.

#### PACKING THE HEATER

1. Allow Heater to cool (20 minutes) before attempting to disassemble.
2. Screw in the folding wing nut on top of the Heater as far as it will go, or the unit will be too long to fit in the box.